

## Goal Post Hardware Purchasing Instructions



In advance of your first game, please purchase the following. You can find these items at a hardware store:

1. Two (2) bolts 12" in length (some stores sell them together with nuts and washers as a set - you can purchase them this way, but you will not need the nuts and washers for goal anchors)
2. Two (2) chains that are about 24" in length, with openings large enough to accommodate the bolts.
3. One (1) sixteen ounce rubber mallet

To anchor a goal post: loop one chain around the base of the goal and onto one bolt. Use the rubber mallet to hammer the bolt into the ground at an angle to prevent the goal from tipping. Repeat on the opposite side of the goal.

